MKT ESC JAW WEAR GAUGE

JAW GAUGE

The MKT Esc jaw gauge will work with both the bottom round jaws and the side clamp jaws



BOTTOM ROUND JAW

The jaw gauge will work for either of the two bottom round jaws on a MKT Esc



SIDE CLAMP JAW

The jaw gauge will work for all four of the side clamp jaws on a MKT Esc



SIDE CLAMP JAW

#1 is a new jaw

#2 is a slightly used jaw

#3 is also a used jaw but is worn out



USING THE JAW GAUGE ON JAW 2

Place the jaw gauge into the tooth profile.



As you can see the red is not visible and the jaw reaches the yellow portion of the gauge. This indicates the jaw is still in the 75% to 50% range.



USING THE JAW GAUGE ON JAW 3

Place the jaw gauge into the tooth profile.



As you can see the red is visible and the jaw is beyond the 50% wear. This jaw is recommended to be replaced.





. If you have any questions please click on www.mktpileman.com for your nearest MKT representative.